

Biosan



Biosan
1522 MPS

***FDA Accepted Interventon
Anti-Microbial***

Biosan

1522 MPS

FEATURES & BENEFITS

- **Biosan 1522 MPS** is FDA accepted antimicrobial for use in FSIS locations.
- Approved for **online and offline reprocessing**
- **Use at low concentrations** for broad-spectrum kill of gram-positive and gram-negative bacteria.
- Effective against Staphylococcus aureus, Escherichia coli, and Salmonella enterica.
- Can be **used as an acidifier** in scald tanks and as an antimicrobial agent

SPECIFICATION DATA

Color	Colorless
Physical State	Liquid
Odor	Pungent, vinegar odor
Flash Point °C (°F) DIN	77°C
Miscibility	Completely Miscible (100%)
pH	0.92 at 25°C
Vapor Pressure	22mm Hg (25°C)
Relative Density	1.138 at 25°C
Freezing Point °C (°F)	-49 (-56)
Weight Per Gallon	9.44 lbs./gal
Active Ingredient(s)	Peroxyacetic Acid - 15.9% Hydrogen peroxide- 23.34%
Other Ingredient(s)	Acetic Acid, Water, Stabilizer
DOT Classification	UN 3109 Organic Peroxide, Type F, Liquid Peroxyacetic Acid, 5.2 (8)
Part Numbers	5311 5 gal 5312 15 gal 5313 55 gal 5314 265 gal

DISCLAIMER

All information and statements contained herein are believed to be accurate at the time of publication, but AgroChem, Inc. makes no warranty with respect thereto, including but not limited to any results to be obtained or the infringement of any proprietary rights. Use or application of such information or statements is at user's sole discretion, without any liability on the part of AgroChem. Nothing herein shall be construed as a license of or recommendation for use which infringes upon any proprietary rights. Use of this product shall be the sole responsibility of user, and AgroChem shall not be liable in any way for said use, other than reimbursement for the actual cost of product.

USES

BIOSAN 1522 MPS is a peroxyacetic acid-based microbicide developed for use in Federally Inspected meat, and poultry processing locations. If used as directed, it will help to reduce contamination and cross-contamination of edible food products. Its use is acceptable for direct or indirect contact in or on food, including fruits, vegetables, meat, and poultry in accordance with 21 CFR 173.370 and 21 CFR 173.315. EPA labeling or approval is not required herein in accordance with ARTCA, 1998 under FFDCA #201(q)(1)(B)(i) if used as directed.

DIRECTIONS FOR USE please see label.

COMPATIBLE MATERIALS

Compatible with: PTFE: Polytetrafluoroethylene, 316 Stainless steel, PVDF: Polyvinylidene Fluoride, HDPE: High Density Polyethylene, Kalrez®: Dupont-Perfluoroelastomer

PUMP

Teflon diaphragms and Teflon, polypropylene, or kynar liquid contacting points. Double seated check valve and de-gassing head. Do not use elastomer composite material for seats or gaskets other than Teflon. Peristaltic pumps can be used. – Santoprene squeeze tubes. Check integrity of squeeze tubes regularly.

TUBING

Teflon Tubing is preferred. FEP or PFA Teflon tubing has good pressure and wear resistance, and is UV and weather resistant. Low density polyethylene tubing is not recommended. High density polyethylene has relatively good resistance but will become brittle with time. Never use any synthetic tubing other than those discussed above

METALS

Never use brass, copper, iron, or galvanized metal of any kind that will contact even the most dilute solution of OXYSAN 15 Acid Sanitizer.

STORAGE AND HANDLING

Store product in original container, in an upright position. The storage area should be well ventilated and shaded from sunlight as well as protected from sources of radiant heat. Contamination of the product, especially heavy metal ions and alkali, must be avoided. Do not store near reducing agents, fuels, organic material, or other noncompatible materials. Avoid temperatures above 86 F. Use first in, first out storage management. Containers must be vented.

Shelf life is at least one year without notable loss of active oxygen if stored properly.

ALWAYS wear gloves, goggles or face shield, and other appropriate chemical resistant gear.

For First Aid & Safety please refer to SDS.